

Drawband Clamp

Data Sheet



Drawband Clamp

Triatek's Drawband Clamp is a duct band clamp connection available for 8" – 14" diameter ducts and provides a simple, leak-free connection for round ducts using a neoprene gasket for a chemical-resistant seal. The double-bolt connection provides superior structural integrity.

This Drawband Clamp is designed specifically to fit Triatek Venturi Valves, and other drawband models may not work with Triatek's Venturi Valves.

| Triatek Drawband Clamp Item Number | |
|------------------------------------|------------|
| 8" Venturi Valve | N-104 807 |
| 10" Venturi Valve | N-104 808 |
| 12" Venturi Valve | N-104 809 |
| 14" Venturi Valve | N- 104 810 |

Product specifications are subject to change without notice.
Triatek is a registered trademark of Triatek LLC. 100110

FEATURES INCLUDE

- Double bolts for superior connection to duct work
- Neoprene gasket
- Available in 8", 10", 12", and 14" diameters
- Airtight
- No end preparation of ductwork required
- For plain or spiral round duct work
- No protrusion into the airstream makes it the ideal connector for ducts carrying dust, etc.
- Reduces installation time
- Cost-effective method for valve removal without any damage to the duct work, as connections and ducts can be disassembled and reassembled