

FMS-1655R

Remote Display

Data Sheet



FMS-1655R with Safety Halo™

Triatek's FMS-1655R Remote Display is powered by its corresponding FMS-1655 Room Pressure Controller, and provides a secondary location to monitor critical environments.

Applications for the FMS-1655R include isolation rooms with adjacent anterooms, nurse's station displays for a single isolation room or patient room, surgical suites with dual displays (one inside the controlled space, one outside), and remotely displaying the room temperature or relative humidity.

The FMS-1655R features a user-friendly touchscreen with modern graphics, intuitive menus, and Triatek's signature color-coded Safety Halo™ edge lighting.

It instantly updates as room conditions change and immediately alerts staff of unsafe conditions with both visual and audible alarms.

FEATURES INCLUDE

- Full-color, user-friendly touchscreen
- Available in surface or stainless steel flush mount
- Intuitive control menus, easy to set up
- Safety Halo™ edge lighting for 180° visibility
- Up to 10 user passwords
- Powered by the FMS-1655
- Audible and visual alarms
- Display any one of the six parameters monitored by the companion FMS-1655
- Status-only display mode available

FMS-1655R

Remote Display

Data Sheet

FMS-1655R Specifications	
Monitoring Capacity	One of six parameters monitored at FMS-1655
Interface Cable	Belden 3107A, 22 AWG
Power Supply	12-36Vdc, 150mA (supplied by FMS-1655)
LCD Size and Type	3.2" diagonal, transmissive
Resolution	240 pixels by 320 pixels, portrait
Viewing Area	50.60 mm x 66.80 mm
Color Depth	18-bit or 262K colors
Backlight Color	White LED
Luminous Intensity	min 2500 cd/m ²
FMS-1655R Mounting Options	Plastic surface mount Stainless steel flush mount
Plastic Surface Mount Housing Dimensions	3"W x 5"H x 1.13"D
Stainless Steel Flush Mount Housing Dimensions	5.1"W x 8"H x .75"D
Operating Temperature	32°F to 125 °F
Operating Humidity	10% to 95% RH, non-condensing
Agency Listings	FCC Part 15
Password Protection	Up to 10 user passwords
Alarm Indication	Safety Halo™ 180° visual indication Industry standard status colors with action icons
Alarm Silence	Touchscreen, auto-reset

Product specifications are subject to change without notice. Triatek is a registered trademark of Triatek LLC. 10212013



Color-coded screens immediately alert users of the room status



Sleek stainless steel flush mount, perfect for busy hallways



The flush mount option is great for shallow wall cavities

Part Number Guide

FMS1655R - 

Mounting Option

F = Flush Mount

S = Surface Mount

